ZWToolbox 2020



Krzysztof Ruszyński Izabela Cholewa

ZWToolbox 2020

Version 2020.0.01 (01-08-2019)

All rights reserved including the right of reproduction in whole or in part in any form. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, without prior permission from Usługi Informatyczne "SZANSA" - Gabriela Ciszyńska-Matuszek.

All signs found in the text are trademarks or registered trademarks of their respective owners. Usługi Informatyczne "SZANSA" - Gabriela Ciszyńska-Matuszek has made its best effort to deliver complete and reliable information within this manual.

The firm shall not be held liable for the usage, or for any potential breach of patent or copyrights included within the manual.

Usługi Informatyczne "SZANSA" - Gabriela Ciszyńska-Matuszek may in no way be held responsible for damage that may occur as a result of and/or when using the information found within the manual.

Usługi Informatyczne "SZANSA" - Gabriela Ciszyńska-Matuszek

ul. Świerkowa 25 43-305 Bielsko-Biała NIP 937-212-97-52

www.zwcad.pl tel. +48 33 307 01 95

Copyright © Usługi Informatyczne "SZANSA" - Gabriela Ciszyńska-Matuszek



Table of Content

1	Des	scription6
2	Red	quirements6
3	Sup	oport6
4	Inst	tallation of application6
5	Act	ivation7
6	Fur	nctions13
6	5.1	Save a file with backup
e	5.2	Inserting points with description and auto-numbering
6	5.3	Numbering polyline vertices
6	5.4	Saving coordinates of elements to a *.csv file
6	6.5	D ² Loading points from a *.csv file
6	5.6	Saving selected coordinates in a *.csv file
e	5.7	Drawing points, lines or spline
e	5.8	Changing the settings of drawing an axis
e	5.9	Drawing an axis
6	5.10	Inserting an axis into an object
e	5.11	Crawing an axis as an arc
e	5.12	Drawing an axis by offset
e	5.13	Changing the letter case
e	5.14	ABC ABCConverting text to polyline
e	5.15	ZtxtChanging the content of the text
e	5.16	Counting number of blocks
e	5.17	Saving information about blocks and their attributes in a *.csv file
e	5.18	Add blocks based on data from .csv file25
6	5.19	Quick Block
e	5.20	Add to block
e	5.21	Remove from block

6.22	Total length of the line	. 28
6.23	Total length of an arc	. 29
6.24	Total length and circumference of objects	. 29
6.25	Total surface area of selected objects	. 30
6.26	Counting the length of a line between indicated points	.31
6.27	Transforms circles into different objects	. 31
6.28	Points, blocks and circles report	. 32
6.29	mmScale drawing from inches to millimeters	. 33
6.30	inchScale drawing of millimeters to inches	. 34
6.31	Aligning objects horizontally	. 34
6.31.	1 Aligning objects to top	. 34
6.31.2	2 Align objects to the center	. 35
6.31.3	Align objects to the bottom	. 35
6.32	Aligning object vertically	. 36
6.32.	1 Align objects to the left	. 36
6.32.2	2 Align objects to the middle	. 36
6.32.3		
6.33	Align a group of objects	. 36
6.34	Rotate with Copy	. 37
6.35	Array of objects by points	. 38
6.36	Mirror by point	. 39
6.37	Extended trim	. 39
6.38	Grating	. 40
6.39 6.40	T Uraws a series of arrows alongside points	
6.40	XAdd arc XRemove points	
6.42 6.43	+ Add point	
6.44	Remove point Activation	
6.45		
0.45	ZWToolbox 2020 User Manual	. 40

	Updating ZWToolbox 2020	
	Manual load menu Manual load application	

1 Description

ZWToolbox is a set of tools which help you to work within ZWCAD environment by means of automating commands.

2 Requirements

The program is an overlay, otherwise known as an add-on, for ZWCAD 2020. The requirements are the same as for ZWCAD 2020 Professional.

3 Support

Technical support is available from 8am to 4pm from Monday to Friday, we are more than happy to answer any questions by phone or e-mail.

E-mail: pomoc@zwcad.pl Phone: 33 474 04 03

4 Installation of application

The installation begins automatically after running the file ZWTOOLBOX_2020.exe.

The Default installation path is C:\Szansa\ZWToolbox\2020\EN. It is possible to choose a different installation path, however it is not recommended. Installing the program in the folder Program Files on the operating systems such as Windows Vista, Windows 7, Windows 8 and Windows 10 can cause major implications because of the built in User Account Control in the given operating systems. The User Account Control can block numerous functions of the program.

Once the installation completes and the user opens ZWCAD, the software ZWToolbox should load automatically. A toolbar presented below will appear on the screen.



If for some reason the toolbar is not displayed, it is possible to run the application manually: Manual load application

5 Activation

A trial period that lasts for 30 days with full functionality is available after installation of the application.

Activation must be completed on an account with administrative privileges.

Once the trial period of 30 days runs out, a license will be needed in order to use the program. After receiving the payment, an e-mail with an activation code will be sent.

Activation is available directly in ZWCAD or by using the function "Activation" from menu of the application. It is also possible to activate the program from its installation folder. By default located in: C:\Szansa_Nazwa_Aplikacji_\2020\PL and run Aktywator_2020 .exe.

In operating systems such as Windows Vista, Windows 7, Windows 8 and Windows 10 it is necessary to right click on ZWCAD icon and select *Run as Administrator*.

Full license code is only visible on the license certificate that is sent out during completion of the order due to security reasons.

Application	Module	Version	Licence type	Licence state	Expiring	The code	
ZWNesting	All	2020	Not for resell	Active			-
ZW Traffic	All	2020	Not for resell	Active			-
ZWTextile	All	2020	Unknown	Unknown			
ZWTextile	Base	2020	Unknown	Unknown			
ZWTextile	Plot	2020	Unknown	Unknown			_
ZWTextile	Female clothi	2020	Unknown	Unknown			
ZWTextile	Import	2020	Unknown	Unknown			_
ZW Toolbox	All	2020	Test	Active			
ZWMetric	All	2020	Unknown	Unknown			
ZWBlocks	All	2020	Not for resell	Active			_
ZWGeo	All	2020	Not for resell	Active			_
ZWDrill	All	2020	Unknown	Unknown			
ZWDraft	All	2020	Unknown	Unknown			

Once Activator has been launched, the following window will be displayed:

Please click on "Activate".

A choice between activating the appliaction online or offline will be present.

Activation		
Online	Offline	
	Activation code	
	Activate	
		Close

Online Activation

Please note: Online activation requires an Internet connection. If there is no internet connection available please use the Offline Activation (Błąd! Nie można odnaleźć źródła odwołania. Offline Activation).

In the field "Activation code" please type in the information sent during realization of the order, afterwards click on "Activate".

An information window will pop up confirming the activation.



Once ZWCAD is launched, all functions of the program should be loaded and

available.

Offline Activation

In the "Offline" tab

Online Offline

additional steps are required to complete the

activation.

Activation		- C X
Online	Offline	
	Activation code	
1:	Create request file	_
2:		
3:	Activate	
		Close

In the field "Activation code" please type in the information sent during realization of the order.


Activation code				
Activate				

Afterwards it is necessary to click on "Create a request file", it will create an additional file which needs to be saved on the desktop or in any other directory of the computer.


1: Create request file	
------------------------	--

The file needs to be sent in a form of an attachment to, pomoc@zwcad.pl and a reply

will consist of response file which then needs to be loaded in the activator:



An information window will pop up confirming the activation.



Once ZWCAD is launched, all functions of the program should be loaded and

available.

Transfer of a license

The license of UISZANSA applications in the form of a program code can be transferred to a different workstation.

In order to transfer the license to a different computer, it is necessary to return the active license and once that is done, it will be possible to activate the license on a different Workstation.

Returning the license

License return is available in the UISZANSA Activator window.

Application	Module	Version	Licence type	Licence state	Expiring	The code	1
ZWNesting	All	2020	Not for resell	Active			
ZW Traffic	All	2020	Not for resell	Active			-
ZWTextile	All	2020	Unknown	Unknown			
ZWTextile	Base	2020	Unknown	Unknown			
ZWTextile	Plot	2020	Unknown	Unknown			
ZWTextile	Female clothi	2020	Unknown	Unknown			
ZWTextile	Import	2020	Unknown	Unknown			_
ZW Toolbox	All	2020	Test	Active			
ZWMetric	All	2020	Unknown	Unknown			
ZWBlocks	All	2020	Not for resell	Active			-
ZWGeo	All	2020	Not for resell	Active			-
ZWDrill	All	2020	Unknown	Unknown			_
ZWDraft	All	2020	Unknown	Unknown			

Once "**Return**" has been clicked on, an additional window will appear in which it will be possible to return the license, either online or offline.

License retu	im	
Online	Offline	
	Activation code	
	Return	
		Close


Online return

Please note: Online return requires an Internet connection. If there is no internet connection available please use the Offline return (3.1.2 Offline return).

To carry out the online return, please type in your license details followed by clicking

on "Return" .

Once confirmed, the license will be usable on a different workstation.



Offline return

In the	"Offline"	tab

Online Offline

additional steps are required to complete the

return of a license.

License ret	urn	
Online	Offline	
	Activation code	
1:	Create request file	
2:		
3:	Return	
		Close

In the field "Activation code" please type in your license details.

Activation code		

Afterwards it is necessary to click on "Create a request file", it will create an additional file which needs to be saved on the desktop or in any other directory of the computer.

1.	Create request file
1.	Create request file

The file needs to be sent in a form of an attachment to, <u>pomoc@zwcad.pl</u> and a reply will consist of response file which then needs to be loaded in the activator:

	_	
~		
2.		

Response file needs to be saved on the computer and its localization needs to be

determined by clicking on the following icon

Once the response file is loaded, click on "Return"



Once ZWCAD is launched, all functions of the program should be loaded and available.

6 Functions

6.1 Save a file with backup.


This feature allows you to save a file with an automatic backup (the backup is formatted as follows "name_year-month-day_hour.minute.second").

🔤 Project.dwg 📄 Project.dwl 🔤 Project_2017-09-27_10.02.40.dwg


6.2 Sinserting points with description and auto-numbering

You will have to enter a name of a series and the first number. Next points selected by you will have text included with a description which includes the name of a series and a number of the next point.

1. After running the command, you have to choose a data point in the command bar.



Enter the series number and enter the start number:



2. Insert a point in the drawing:

	+ 🕞 🚹 🖉 + . 4 «	eress Online APP+		Reat C. ®	ByLayer —— 0			1		
ne Polyline Circle Arc 🔲 🛆 O Ma	ove Copy Stretch Fillet ங 💣 😥	Text - III - Pro	perties 🗣 🗰 🖬 punkty 🔹 🔹			ByLøyer		Paste 🗳		
Draw	Modify	Annotation		Block	Proper	rties		Clipboard		
1 - 2 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -		N (5 12 🔿 🎘 🗗 💻								
Drawingl.dwg	a.dwg X 📑			4 D × 10 –	Calcula				Properties	
					0 V		* =		No selection	- ® d
									General	
										ByLayer
					Number	Pad<<				
			35/30							
									View	
					Scientifi	ic<<				
					Variable	:s>>			Misc	
					Units C	onversi	on>>		UCS Icon On	
F H model NB-1 erie:35/					Text Ca	lculate>				
tart number:30										
85/30*cancel* Command:										

3. The program allows you to automatically insert points by indicating the location.

Numbering polyline vertices 6.3

This function is used to automatically number polyline vertices from a selected starting number, e.g. a2. It is possible to create a block in which next numbers will be added. An example of usage is presented below:


1. Selet a block with an attribute which will appear on vertices of the numbered polyline, for example:



2. Now select a polyline to describe vertices, for example:

3. In the command bar name the series, e.g. a

4. Enter the starting number (it is set to 1 by default), in this example we will use 2. Confirm with enter and the result will be presented below:



6.4 Saving coordinates of elements to a *.csv file.

After running the command, ZWToolbox will ask you to select objects with descriptions that need to be exported. Then, you have to select the destination path in which the file will be saved. It is possible to save the coordinates of objects such as: line, polyline and point. The correct filename extension in which the file should be saved is .csv

The format in which the coordinates are stored is as follows: Description;X;Y;Z

-coordinates will be separated by semicolon "; "


-decimal places will be separated by commas ", "

- Description will be added to elements which were inserted by using the 🔎

function.

Example of a line of data: d5;83,1082;1271,6697;0

1. After running the command, ZWToolbox will ask you to select the wanted objects.



2. Confirm with Enter and then find a location on your disk, enter the name of the file and click save.

Get file name	to load						×
Save in:	EN EN		× .	💌 🔕 🛩	⊻iew	• Tools	,
Hintoy Desktop Desktop Ø Ø Ø Favorites Favorites		Ten folder jest pusty.		Preview			
	File game:	Files.csv			<u> </u>	Save	
	File type:	*.csv			\sim	Cancel	


3. The coordinates of chosen objects will be visible in the new file.

	А	В	С	D
1	35/36	7429766.6	5549118.1	0.0000
2	35/35	7429766.8	5549118.6	0.0000
3	35/34	7429767.9	5549118.5	0.0000
4	35/33	7429768.9	5549117.2	0.0000
5	35/32	7429769.2	5549118.2	0.0000
6	35/31	7429770.2	5549118.2	0.0000
7	35/30	7429769.9	5549120.1	0.0000
8	35/29	7429768.8	5549121.3	0.0000
9	35/28	7429767.9	5549121.6	0.0000
10	35/27	7429766.9	5549120.8	0.0000
11	35/23	7429766.3	5549116.8	0.0000

6.5 \bigcup Loading points from a *.csv file.

After running the command, you need to select a file which contains the coordinates of points. The file needs to be in the .csv format.

1. Run the command and select the file which contains the coordinates.



2. The points will be loaded into a drawing.

ņe F	Polyfine Circle Arc	0.50 ∷.60 	Copy Stretch Fillet	/ @ ≪ □ - 8 % • 8 © • • • 0		RR77778 888288 888288 •***■0	Insert	ByLay	ByLøyer ByLøyer		Paste			
	Draw 1 10 17 19 10 11		Modify		Annotation		Block	Prop	perties		Clipboar	đ		
	Drawing1.dwg	🗙 🤯 Etykieta.dw	s 📑						alator				Properties	
							- a x		Ф Б				No selection	• 🖲 🖪
													General	
														ByLayer
						967 								
								Numb	er Pad<	< sqrt				
													View	
								Scien	tific<<					
								Varial	bles>>				Misc	-
								Units	Conver	sion>>				
E E								Text	Calculati					
Comma	and: 'zoom ify corner of window	u and enter a scale	facton (ex on exp)											
[A11/	/Center/Dynamic/Exte	ents/Left/Previous/	Scale/Window/Object] <real time="">: _e</real>										
Comma	and:													

6.6 Saving selected coordinates in a *.csv file.

Firstly, you will be asked to select points. Once all the wanted points are chosen, you will have to select a file path where you want the points to be saved.

The format of coordinates stored in the file will be following: ;X;Y;Z

-coordinates will be separated by semicolon "; "

-decimal places will be separated by commas ", "

1. After running the command, you need to choose the points on the drawing and

confirm by pressing "Enter".

	I F F F MOUEL / RB-1 /
\times	Command: T_PtExport
	Pick point: 7429766.0986, 5549117.8647, 0.0000
	Pick point: 7429764.9731, 5549119.9179, 0.0000
	Pick point: 7429767.4842, 5549120.0966, 0.0000
	Pick point:
7	.429767E+06, 5.549120E+06, 0.00000000 🛛 🖽 🖽 🗠 🕝 🛄 🔼 🛃 🖶 🔳 📷

- 2. A window will appear which lets you name and save the file.
- 3. Previously saved data will be displayed in a new file.

	А	В	С
1	7429765.6	5549120.5	0.0000
2	7429767.3	5549118.8	0.0000
3	7429767.1	5549117.4	0.0000
4	7429764.8	5549117.0	0.0000
5	7429766.8	5549117.9	0.0000
6	7429767.5	5549117.2	0.0000
7	7429769.3	5549119.0	0.0000
8	7429762.0	5549120.1	0.0000

6.7 Drawing points, lines or spline

This function allows you to insert points into the drawing with coordinates from a text file, connect the lines (with a straight line) or by using a spline.

Draw from file	×	
Data file		
Select file		
Scale X: 1 Y: 1 Z: 1		
offset X: 0 Y: 0 Z: 0		
Draw Point Line Spli	ie	
Close		
	*	

6.8 Changing the settings of drawing an axis

This function lets you determine the layer on which the created axis will be placed and by how much they should extend outside of the object. The length of the extension can be determined numerically or in percentages by selecting the option as shown on the picture below:

Settings	×
Axis layer Axis length ☑ Length in	osie 5 percent?
Save	Cancel

6.9 Orawing an axis

This function draws an axis between two points on a layer that was previously determined in the settings.

1. After clicking on the command, select two points on the drawing where you want the axis to be inserted.


Image: Solid Annotate Insert 20 Diating Home Solid Annotate Insert Venus Image: Solid Constraints Insert Image: Solid Image: Solid Constraints Image: Solid Move Constraints	lools Manage Export Express Online APP+ ■				ylayer Ylayer	•••	in X		_ 🗆 ×
Draw 6 2 2 2 17 18 27 18 27 10 17 18 18 18 18 18 18 18 18 18 18 18 18 18	Modify Annotation	Layer Z. 🗔 🗔 🕼 🛠 🕂 🗙 🖽 🖽	Block	Proper	ties		Tipboard		
Drawing1.dvg X Etykieta.dvg			٩Þ						
			- a ×	0	6	• =		No selection	- 🕒 di 🗸
								General	
								Color	 ByLayer
	35/18								
				Number	Padee				
					K ++				
								View	
				Scientifi	c<<				
Y	35/2								
1	5512								
				Variable	s>>			Misc	
d→ X				Units Co	inversio	n>>			
<pre>4 《 F F model Lavouts Lavouts Pick fist point of axis:</pre>				Text Cal	culate>>				
Pick second point of axis: Command: _Regen									
Command: _Negen Command:									
Command:									
484.5887, 102.7986, 0.0000									☆ 53

2. Once the two points have been selected, an axis will appear on the predetermined layer.


6.10 \bigoplus Inserting an axis into an object.

Once you click on the command, you will be asked to choose any number of arcs and circles.


a) When clicking on an arc, a circle or an elipse, an axis will be automatically added on a layer determined in the settings window.




 b) By selecting two arcs or circles you will add an axis similar to the one on the picture below:



c) If you choose more than one arc or circle, an axis will appear similar to the one pictured below:



d) By selecting two lines you will insert a symmetry axis between those lines. The length of the axis can be determined if the user selects two points (they will be shown on the axis).



6.11 **•** Drawing an axis as an arc

This function will let you draw an axis in a shape of an arc.

The function will ask you to enter the following in the given order: center point of an arc, the starting point of an arc which will simultaneously define the radius and the end of an arc.

· · · · · · · · · · · · · · · · · · ·		- 4 « 🖉 📔 💾		 Insert 🛛 🔳	ByLayer ————————————————————————————————————	yLøyer	:	- <u>*</u>			
			Properties ♥ ☆ ㎡ ■ 0			lyLøyer		•			
Draw 🖌 🖞 🗗 👘 🔂 💌 🖉 🍕	Modify C N B S B + F /	Annotation		Block	Proper	bes		pboard			
		inne.dwg 🗙 📑		A P	Calcula	tor					
				_ 0 ×	2 Q			Δ×		No selection	- 🖲 💐
					• •			4 ^		No selection	
										General	
											ByLayer
					Number						
										View	· ·
					Scientifi	r{{					
									10°x		
					Variable	\$>>					
					Units C	inversion				Misc UCS Icon On	
H Model Arkuszi Arkuszi					Text Ca	culate>>					
mmand:											
ommand: ommand: REGEN											

Drawing an axis as an arc is useful in situations such as designing an outline of a screwthread.

6.12 Drawing an axis by offset

You will be asked to select an object to offset, then the direction of an offset by clicking a selected point. Lastly, you need to set a certain distance to offset.

Y Y						
Image: State with the law in the la	📌 🚬 🖿 🗮 🗮 🗮 🗣 🐑 🛧 + 🖉 🔹 2D Dirafting & Annotati 🔹 📔 ZWCAD 2018 Professional Edition - [CAUsers/szabela/Desktop/ZWToolbox 2018/sosie wyrownanie i inne.dwg]					_ 🗆 ×
Drew for a construction Drew for a construction <td>📲 Home Solid Annotate Insert Views Tools Manage Export Express Online APP+ 🖬</td> <td></td> <td></td> <td></td> <td></td> <td></td>	📲 Home Solid Annotate Insert Views Tools Manage Export Express Online APP+ 🖬					
Unit of the second of the s		ByLøyer		💼 X		
Des Mody Ancodos Des Des Dependir Cupando Image: Strates and the set of the			yLayer	Dante R		
• • • • • • • • • • • • • • •						
Image: Structure region Image: Structure region <td></td> <td>Proper</td> <td>ties</td> <td>Clipboard</td> <td></td> <td></td>		Proper	ties	Clipboard		
Y Y						
Y Value Part(Convert Sole calculation Y		Calcula	itor		Properties	×
Y Numer Part (_ # ×	🥏 🍳	1 5 1		No selection	🗕 🖷 🗸
Y Numer Pace						^
Y Commit: Scientific: Commit: Scientific: Scientif					General	-
V V <td></td> <td></td> <td></td> <td></td> <td></td> <td>ByLøyer</td>						ByLøyer
Y Number Perfect Number Perfect Langing at 1 Langing						0
Y Number Perfect Number Perfect Langing at 1 Langing						
V Isolation in the set of the s						1
Y V V V V V V V Y V V V V V V V Y V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V V Consult: Consult: V V V V V Consult: Consult: Consult: V V V V						- Bulaver
V Image: Signal State St						
V V <td></td> <td></td> <td></td> <td></td> <td></td> <td>·</td>						·
V 1 0						-
V Single Singl						
Y Scientific V Common 2 Scientific V ScientV Scientific V Sci						
Image: Second		Scientifi	in < <			
Image: start in the s						
All db abs mid mod mod Variable:>> Variable:>> Mod mod Variable:>> Variable:>> Variable:>> Variable:>> Commad:: Commad:: VCS into it might the	Y					
Mark Mark Mark consult Consult Consult Consult Consult	Λ					2741.7068
Mark Mark Mark consult Consult Consult Consult Consult						
A S M Well Alust Annu Alust Alu	4				Misc	~
Consult: Consult: Consult: Consult: Consult:	□> X	Units C	onversion		UCS Icon On	Yes
Consult:	4 4 9 10 Model Antusti Arkust2	Text Ca	lculate>>			Yes
Consult: 1						Yes
						~
	Command:					
	4582,511,-1295,6883,0.0000					\$ 8

6.13 A Changing the letter case

This function lets you change the size of the letters. This does not mean that the font will change but instead the letters can be made big and small, various possibilities of the letter size are in included in this function.

1. First of all, you have to select a text object on the drawing field.



2. A window will appear which will let you to change the size of the letters.

тс	ASE-change text case	×
	● Sentence case	
	◯ <u>l</u> owercase	
	○ <u>U</u> PPERCASE	
	<u>◯ T</u> itle	
	⊖ t0 <u>G</u> GLE cASE	
	p	
	OK Cancel	

3. Once the option has been picked, you have to confirm it by clicking "OK". The program will adjust the letter size of the chosen text.

6.14 ABC Converting text to polyline

Allows for the selected text to be converted into a group of polylines.

1. Select the text which is to be converted and confirm by pressing "Enter"



2. Afterwards, contours of selected letters will appear and those are called polylines.



6.15 ZtxtChanging the content of the text

This function enables you to change the existing text by using the options shown below:


Text modification	×
Prefix Suffix	
Overwrite old text	
Autonumeration	
Turn On autonumeration	
Start Nr Ste	p
Text placement	
● Begin ◯ Before ◯ Aft	er 🔘 End
Tekst	
OK Cance	el

Depending on how you want to modify the text, you can use a prefix or a suffix. You can also add auto-numbering to the text (but you have to remember that only numerical values can be entered) You can also add a starting number, and an initial step which determines the number by which the values need to increase. To confirm the settings we have to press the button "OK" and choose the text which needs changing.

6.16 🤁 Counting number of blocks

This function counts the number of selected blocks.

1. After activating the command in the toolbar,3 options become available.



- 2. Information about counting the amount of blocks needs to be entered:
 - Layer counts the number of blocks on a selected layer
 - Selection Set counts the number of a selected block
 - All counts the number of all the blocks inside the drawing

X	Command: _BLOCKSUM Enter an option [Layer/Selection set/All] 475 blocks in this drawing.	<all>:</all>
	Command:	
7	.429767E+06, 5.549119E+06, 0.00000000	_ 🌐 🌐 L 🕝 🗋 🗹 💆 늘 ≡ ኬ 🌉

After you enter all the information, number of blocks included in the drawing will be displayed in the command line.

6.17 Saving information about blocks and their attributes in a *.csv file

This function is used to save information and parameters of the blocks. By using the command *eattext*, all of the parameter rs of one block will be saved (in Excel) in one cell, divided by commas:

```
"Ilość","Nazwa","A/B","Skala X","Skala Y","Współrzędna X","Współrzędna Y","Obrót"
"1","SAP","1/1","0.7349","0.7349","2110","1455","0"
"1","SAP","1/2","0.7349","0.7349","2322.4221","1651.4741","0"
"1","SAP","1/3","0.7349","0.7349","2583.7374","1864.2293","0"
"1","SAP","1/4","0.7349","0.7349","2606.2347","1400.665","0"
"1","SAP","1/5","0.7349","0.7349","2971.3839","1308.99","0"
"1","SAP","1/6","0.7349","0.7349","3083.8706","1680.8793","0"
```

In order to divide certain parameters into different columns, for instance the reasoning might be a process which requires only a selected amount of information, please choose the

first column and move onto the tab called *Data*, secondly click on the option *text as columns*. A window will appear, please press *Next*

Kreator konwersji tekstu na kolumny - krok 1 z 3	x
Kreator tekstu ustalił, że dane zawierają separatory. Jeśli tak jest, wybierz przycisk Dalej lub wybierz typ najlepiej opisujący Twoje dane.	
Typ danych źródłowych Wybierz typ pliku, który najlepiej opisuje dane źródłowe:	i.
Podgląd wybranych danych: 1 Tlość, "Nazwa", "Symbol", "Powierzchnia", "Długość", "Przeznaczeni 2 1, "+U27", "", "", "", "", "", "", "", "", "",	e" ^
Anuluj < Wstecz Dalej > Zak	(ończ
Kreator konwersji tekstu na kolumny - krok 2 z 3	
Ten ekran umożliwia ustawienie ograniczników zawartych w danych. Ich wpływ na tekst można obejrzeć na podglądzie poniżej.	
Ograniczniki Tabuiator Śrgdnik Ø Przecinek Spacja Inny:	
Podgląd danyc <u>h</u>	
Tlošć Nazwa Symbol Powierzchnia Dżugość Przeznaczenie Pow_mb DDLE / 1 +U27 1 k-12b 1 k-14 4 k-16-	
Anuluj < Wstecz Dajej > Zakończ	

Please click Next, and Finish.

On the right side of the window, as a form of restriction, *Tabulators* are turned on. Please turn them off by clicking on them and please turn off *Comma* as well. A window will appear showing a preview of the document.

6.18 PAdd blocks based on data from .csv file

It is possible to add blocks with attributes which are defined in the current drawing. The block will be added according to the parameters define in the *.csv file. An example of a file with parameters is shown below. The sequence of columns can be changed however the titles: Name, Scale and coordinates cannot be changed. Remaining titles are treated as name of attributes, of which values are displayed in the lines below.

	А	В	С	D	E	F	G	Н	
1	llość,"Nazy	va","NPR",	"WSR","Ska	ala X","Skal	a Y","Wspó	łrzędna X",	"Współrzęd	lna Y","Wsp	oółrzędna Z"
2	1,"DIN","","	","0.7000",'	0.7000","12	.2151","61.	9837","0"				
3	1,"DIN","","	","0.7000",'	0.7000","15	.9897","59	0883","0"				
4	1,"DIN","","	","0.7000",'	0.7000","19	.6487","64	7804","0"				
5	1,"DIN","","	","0.7000",'	0.7000","20	.6438","61.	3189","0"				
6	1,"DIN","","	","0.7000",'	0.7000","27	.6999","62.	.67","0"				
7	1,"DIN","","	","0.7000",'	0.7000","29	.999","71.2	043","0"				
8	1,"DIN","","	","0.7000",'	0.7000","38	.7537","46.	6019","0"				
9	1,"DIN","","	","0.7000",'	0.7000","62	.3155","34.	2319","0"				
10	1,"DIN","","	","0.7000",'	0.7000","64	.7954","35.	4517","0"				
11	1,"DIN","","	","0.7000",'	0.7000","67	.7689","40	6049","0"				
12	1,"DIN","","	","0.7000",'	0.7000","71	.734","43.4	757","0"				
13	1 "רו ויי ייי יי	" "0 7000" "	0 7000" "0 0	212" "28 5	22" "0"				


An example after the blocks have been imported






Quick Block gives you the option to create a block by target certain objects and pressing "Enter". A step for choosing additional options such as choosing a name or a base point is skipped as they are determined automatically.

From the example below, we can see that elements are divided from each other – they do not create a whole. Thanks to this function, you can create a block from them which will stand as a one, connected element.




Once you select the elements which are to create a block, to confirm press "Enter".






This command allows you to add more elements to the existing block.

- 1. Press Add To Block.
- 2. Select the items you want to add.



4. Select block.



After completing the instructions above, the selected elements will merge into one object with the previously created block.


6.21 Remove from block This function allows you to delete chosen elements from a created block Press Remove From Block Choose the elements which are to be deleted from the block



6.22 🕂 Total length of the line

This function tells the program to sum up the total length of selected lines on the command line.

1. Please select the lines on the area of the drawing and confirm by pressing "Enter". The function does not work on polylines. If you would like to count the length of polylines please use the function **Counting the length of the line between the indicated points.**



2. Once you confirm the action, the command bar will show the total length of chosen

lines.

X 143 found (36 duplicate),Filtered out 54 Select line(s) or polyline(s): Total Length=151.03286256.	9, 143 total
Command:	
7.429766E+06, 5.549118E+06, 0.00000000	_ ▦ ▦ ⊾ 鉧 🗖 🗹 💆 늘 ≡ ங 🌉


6.23 😚 Total length of an arc

The program will sum up the total length of all sleceted arcs and will display them on the command bar.

- 1. Please indicate the arcs that you would like to sum up and press "Enter".

3. Once the action is confirmed, the command bar will show the total length of selected


arcs.




6.24 **Total length and circumference of objects**

This function can be used to sum up the length and circumference of selected objects.

1. Once the command has been clicked on, you have to choose the objects which are to be summed up and confirm with "Enter".




2. As soon as you confirm the action, the command bar will display the total length and circumference of chosen objects.



6.25 Total surface area of selected objects

This function will sum up the surface area of selected objects.

1. Once the command is clicked on, you need to choose the surface area of objects which is to be summed up. Confirm with "Enter".



3. As soon as the action is confirmed by pressing "Enter". The total surface area of chosen objects is displayed.

<pre>1 found, 4 total Select objects: 4 Object(s)(4 valid), Total Area= 4888.13</pre>	157.
Command:	
178.0427, 335.0592, 0.0000	▦ ▦ ⊾ ◙ 🗋 ∠ 🗷 ≒ ≡ ≒ 🕮


6.26 Counting the length of a line between indicated points

This function lets you sum up the length of a line between indicated points. This can be used on lines, polilynes and splines.

1. Once you run the command, you need to choose a line.



2. Afterwards, select two points on the chosen line to calculate the length of the line.



3. As soon as you click on the second point, command bar will display the length of the

line between the chosen points.

X Pick start point: Pick end point: Sum of length equals: 27.0591	
Select object	
271.1502, 228.8680, 0.0000	_ ▦ ▦ ⊾ ◙ 🗖 ∠ 🖄 ≒ ≡ Ѣ 颶

6.27 OTransforms circles into different objects

This function transform circles into objects such as: points, crosses, circles of a selected size, stars and blocks. In order to change an object, you need to enter the diameter of circles

which are going to be changed. The type of a mark that it will be changed to and its color. By doing this all of the circles of a given diameter will be changed to a set mark.


Change circles to marks	×
Diameter to chenge	Select
Mark	
Mark type	Point 🗸
Block name	\sim
Mark size	
Mark color	
Run	Close

6.28 Points, blocks and circles report

This function will ask you to select points, circles and blocks. Afterwards, you will be asked to choose a sorting criteria: do the selected elements in the collection have to be sorted by using the coordinates of X,Y,Z, by the size of the circles or the scale of the blocks. The collection is inserted into the drawing, alongside numbers next to each element. Those are then added to each point, circle and block. An example of such drawing before using this function is as follows:

	Solid Annotate		Views Tools		Export Expres	Gonline AP	P+ ▼	sktop\ZWToolbox 20									_ ¤ ×
Line Polyline Gr		6.0	tre Copy St ove Copy St		/- • & « 8 % - 8 % - 8 %	se Multiline Text •	r∎ - Enger II - Properties			losert		ByLøyer ByLøyer		Paste	> 1 4		
16 a 16 af	Draw To Dia Dia 1			Modify		Annotatic 🕂 👫 🔶 🎽	∽ ● ₽ Σ Σ			Block	Рторе	rties		Clipboard			
🔹 🗟 Etykieta.		asie w		Plan_		apunkty (a punkty.dwg	-	TOOLSunk	Calcul					Properties	×
										- a ×	0 C	è 🖺	•			No selection	🗕 🖓 🖌
																General	
O																	ByLøyer
0			ø			國											0
								Ø	Ø		Numbe	r Pad<<					DyLayer
図					x _				×								1 — ByLayer
\sim						×				Ø							0 byLayer
~																	
o 🕱							2									View	-
_				Э		茵						MS	M+	MR	MC	Center X	542.318
											Scienti	lecc					182.8495
									Ø		sin	cos					0
Y 🖾					Ø												267.7908 724.896
							Ø			Ø							724.070
										щ	Variabl	es>>				Misc	-
	. 🗵					Ø					Units C	onversi	ion>>			UCS Icon On	Yes
H H P P Model	krkuszi Arkuszi					ø			0		Text Ca	lculate:					Ves
Command: Command:																	Yes
Command:																	
Command:																	
637.3887, 275.93	293, 0.0000																\$€

- 1. Once you run the command, please select the points and circles.
- 2. You then need to set a sorting criteria




re Polyline Grote Art 0.0		- • • B					o⊐ ta ■ Irsent ⊟ ⊡		ByLøy er ByLøyer				
		Modify	Annotation				Block	Prope	rties		lipboard		
attykieta.deg a		Rien_drogildwg	punkty okr	egi.dwg 🗙 📑 👓				Calcul	ntor			Properties	
						170.0878 C	- a ×	0	Б			No selection	• % 🖪
					103.438 305.258 327.057	8 114,1103 0 174,0404 0						General	
					7 222.087 6 235.967 6 354.379 70 357.58	16 314.832 6 18 131.5157 6							ByLayer
					11 347.048	17 RAADDA C	10000						
					13 343.553 14 395.464 15 346.120	72 1026131 0 13 1798954 0 10 229.1657 0		Numbe	Ded//				
				† ──	10 411.541 17 412.104 10 414.074	18 224.9254 0 11 59.5775 0		C	<				
					20 401.451 20 444.120 21 445.551	12 1077505 E	1412						
					22 454.071 23 454.071								
প্র		٩			28 478.511 28 452.791	19 92,4342 0 11 105,4691 0							
					27 904402 28 807240 28 420731 30 422691	0 255.4801 0 13 564.2715 0	10022					View	
2					15 533.881	13 116.1103 C	6,9922						
					15 441444 34 454734 36 571,55	45 1554304 C		Scientif	ic<<				
					38 A73.074 37 474.694 38 \$77.894								
Ô					20 994 320 20 994 729 21 910 013	1 201011 C	11122						
					42 413.1 43 425.854 44 451.838	1728284 0							
			3)		41 457.541 40 660.111 47 474.885	11 1199542 C		Variable	:8>>				
	ind.				1 000.000	17 72.4336 6 271.6377 6	19922	Units C	onversio	an>>		Misc UCS Icon On	
>⊠	Ø				50 712,605 51 715,563 52 719,527	89 100,2996 0 15 261,9032 0 7 234,8077 0	1000	Text Ca	(culate)				
<pre>F H Hodel Arkusz1 Arkusz2 F found</pre>													
elect objects: *cancel* command:													

inch


6.29 mmScale drawing from inches to millimeters

If a picture is drawn in the metric scale of inches, and you have to convert it to millimeters, you can use this function in order to do so. This picture will be increased 25.4 times.

Size in inches.



Size in mm



6.30 inchScale drawing of millimeters to inches


If a drawing is in millimeters and you need to convert it to inches, you can do this by pressing the correct icon. The example shows the picture reduced 25.4 times.

- 6.31 Aligning objects horizontally
- 6.31.1 Aligning objects to top

The elements will be aligned to the most furthest upper edge out of the chosen objects, just like on the example.

User could choose the group of objects and after confirmation by ENTER, the objects will be aligned to the the extreme upper edge among indicated objects.

You have to specify the alignment parameters: orientation, alignment direction.



Then please select the objects.

B = = • · · · · · · · · · · · · · · · · ·		r ByLøyer ByLøyer perties		Poste Clipboar		_
🔹 👼 osie w inne.dwg 🗙 👼 Plan_drogi.dwg 👼 punkty okregi.dwg 👼 punkty.dwg 👼 TOOLSunkty.dwg 👼 Przykład_puskt					Properties	× • 🖏 🖪 •
	1	् 🛤	1		No selection	• 10 00 40
					General Color Layer	• ByLøyer 0
		er Pad<				
		er Pad< <				
					View	
	Scient	tific<<				
Y						
A						
	Variab	les>>			Misc	
	Units	Convers	ion>>		UCS Icon On	
L→→→ X (())) Medel Arbuszi Arkuszi	Text C	Calculate				
Select objects: Specify opposite conner:						
3 found Select objects:						
Comand:						
11818.3814, 4143.6911, 0.0000 🗏 🖽 🦶 🙆 🛄 🗹 🔝 🐂 = 🐚 🗃						

6.31.2 Align objects to the center

Chosen elements can be aligned in the middle of the vertical line. The point is designated as a centre of an axis Y with the furthest extended lower and upper edge of the objects. Elements will change their location.

Live Neytor Crief Ar, Son Carlos Car		Løyer — Byl — Byl Propertie	ayer		Paste Lipboari	(.))		_ ¤ ×
●「市田県」の1000000000000000000000000000000000000								
🕈 🍓 esie v inne.dwg 🗙 🎂 Plan_drogi.dwg 🛛 Bpunkty okregi.dwg 🖉 punkty.dwg 🖉 Przykład_pun d		olculato					Properties	×
- 0 ×	* 🧳		6				No selection	🗕 🖗 🚽
							General Color	- ByLayer
								•
	Nu	mber P	ad<<					ByLayer
								1
								— ByLayer
								•
							View	-
								9376.613
	Sci	entifics						4667.7779
								0
Y I I I I I I I I I I I I I I I I I I I								6408.1529
								17346.5409
	Va	riables)					Misc	-
	Un	its Con	versio	in>>			UCS Icon On	Ves
Ċ→→→ X ({ > } hi Model Arturat Arturat Arturat	Tex	xt Calcu	ulate>:					Yes
Select objects: Specify opposite conner:								
3 found Select objects:								~
Comand:								
12020.8695, 3595.7821, 0.0000 🗏 🖽 📙 🛴 🗿 🔂 🖉 🖾 🗮 = 🐚 🐻								⇔ S3

6.31.3 Align objects to the bottom

Elements will be aligned to the furthest bottom edge amongst the indicated objects. Objects will change their location.

		ByLayer	•	Peste 2	6		_ ¤ ×
Draw Modify Annotation Layer Block	Prope	ByLøyer rties		Clipboard			
「「「「「」」」「「」」「「」」「「」」「「」」「「」」」「「」」」「「」」」「「」」」「「」」」」							
📑 💑 osie v inne.dwg 🗙 💩 Plan_drogi.dwg 🛛 💩 punkty okregi.dwg 🖓 punkty.dwg 🖓 1001.5unkty.dwg 🖓 17001.5		ator				Properties	
_σ×	0 Q					No selection	🚽 🛍 🛃 😼
						General	
							ByLøyer
	Numbe						
			sqrt		1/x x*2		
					x*2		
						View	
) MC	Center X	
	Scientif	ic<<					
Y							
A							
	Variable	:::>>					-
	Units C	onversi	on>>			Misc UCS Icon On	
$\hookrightarrow X$	Text Ca	(culate)					
€ € ► ► Model Arkuszi Arkuszi Select objects: Specify opposite conner:							
3 found Select objects:							
Command: 10996.5179.5513.4635.0.0000							¢ (3

6.32 Aligning object vertically

6.32.1 Align objects to the left

After choosing a group of objects and activating the function, they will be aligned to the furthest left edge of the indicated objects.

6.32.2 Align objects to the middle


You have to choose a group of objects and after pressing ENTER they will be aligned to measure the level of the indicated objects. The point is marked as the center of the X axis from the furthest left and right edges of objects.

6.32.3 Align objects to the right

In order to align objects to the right, choose objects and confirm by pressing ENTER. They will be aligned to the furthest right edge of the indicated objects.

6.33 Align a group of objects

This function allows to align the group of objects to a chosen point. Firstly, the user should indicate a certain point, and then point to which the objects are to be moved/adjusted. If the chosen point of outer contour will be for ex. *the end* or center, all the indicated objects will be moved to that point.




If the chosen point of outer contour will be "Close", all the objects will be aligned in the direction of the X or Y to a certain point.




6.34 CRotate with Copy


This function is similar to the standard ZWCAD command Rotate.

It will ask the user to select objects, center point, reference and rotation angle.




Rotation will be done on a copy of a selected object.





This function will ask the user to select elements to copy and select point objects.




Specify the base point of the copied item.

In each selected point, a copy of items will be inserted.

We have Said Avecade Isaid Manage Esport Esport<	xee Multiline Test + Ⅲ + Properties ♥₩ di ■ 0 Annotation Laye		ByLayer	ByLøyer ByLøyer rties		Peste 🕹		_ =>
	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	N & N X & II A A & A						
T. inne.dwg Plan_drogi.dwg Epunkty okregi.dwg Epunkt	TOOLSunkty.dwg	x Przykład_pusty.dwg	Calcul				Properties	× 🚽 🖳 🦣 🗸
			0 N		• =		No selection	- va ce, va
							General	
								ByLøyer
			Numbe					
				r Pad<<				
							View	
#			Scientif	ie<<				
			Variable	:8>>			Misc	-
			Units C	onversi	n>>		Misc UCS Icon On	
$\longrightarrow X \qquad \checkmark$			Text Ca	lculate>				
(()) Model Arkuszi Arkuszi × 1 found, 3 total								
Select objects: 1 found, 4 total								
Select objects:								
	S (2)							\$ 5


The results of the operation is presented on the picture below:



6.36 Mirror by point

Function will make a mirror image of each selected object by X and Y axis.

After activating the command, you have to identify the item that you want to copy and then a base point as the center point of the reflection element.




6.37 SExtended trim

This function trims all the elements which cut through a chosen object


The first step is the indication of the element which is to be cut. Afterwards, you need to

choose a side of the element on which the elements have to be cut.



The results are presented below:

- On the object on the left hand side of the drawing area the lines are cut inside of the selected outline.
- On the object on the right hand side of the drawing area lines are cut on the outer side of the selected outline.



6.38 Grating

This function allows the user to draw vertical and horizontal lines on a selected area. After running this command, the application will ask you to indicate the scope of the drawing grid and then it will ask you for the amount of horizontal and vertical lines.

Please specify two corners of the area where you want gratings to be done.

	Irafting & Annotati • ZWCAD 2018 Profession		abela\Desktop\ZWToolbox 20	18\osie wyrownanie	t inne.dwg]								
\ C (C 0·5 A	• 🕞 🏹 + · e « 🤌	A				ByLøyer			* *				
Line Polytine Circle Arc . S Mov	ve Copy Scale Filet 🐚 🖝 🐻 Frase		Zayer Layer operties 💡 🏶 💰 🗖 0	2 2 2 2	Insert 13		ylayer lylayer		aste 🧳				
Draw	Modify	Annotation	Layer		Block	Proper	ties		lipboard				
1981 - 1961 - 1961 - 19700 - 19700 - 197	🔟 💥 🔛 🕐 💀 🕺 🐼 (4 🛠)				AL 🔊 🍫 🚣								
🔹 👼 osie w inne.dwg 🗙 👼 Plan_drogi	i.dwg 🤤punkty okregi.dwg	🚔 punkty, dwg	👼 T00LSuni	cty.dwg 📑 F	Przykład_pus 📢 🕨	Calcula	tor				Properties		×
					- ª ×	🥏 🝳	6				No selection	🗕 🖳 🗸	2 😼
													^
											General		-
												 ByLøyer 	
													a a a a a a a a a a a a a a a a a a a
						Number	Pad<<						
								9		x*2			
										x*2 x*3			
											View		-
								pi	(Center X		
						Scientifi							
Y													
Å													
Ť						Variable	:8>>						
				p		Units Co	inversio	uu>>			Misc UCS Icon On		
d> X						Text Cal	culate>						
4 4 b bl. Model Arkuszi Arkuszi /													
Command: Kraty Pick first corner:													
Pick second corner:													
-1085.2644, -1838.3394, 0.0000		a											0 50

You have to specify the number of rows and number of columns.

<pre>X Pick first corner: Pick second corner: How many horizontal lines:<0>20</pre>	
How many vertical lines:<20>40	
-1154.5589, -1796.9551, 0.0000	_ = + 6 🗋 🛛 🖉 🖶 = 🐄 🗐


The effect is as follows:

Home Solid Annotate Insert	Views Tools t Move Copy Scal		rase Online APP Multiline Text -	: 🚘	88777788 89482923 ****		∂ ∎,	— ву	Løyer Løyer	•	Paste	5 F		
Draw Re 2 (2) (2) (2) (2) (2) (2) (2) (2) (2) (N 10 11 14	Modify 🚸 📑 🕺 🖄 🖓 (1	Annotation			Block		Properti			Clipboard			
🔹 👼 osie w inne.dwg 🗙 👼 Plan_d		punkty okregi.dwg	📑 punkty . de		TOOLSunkty.dwg	Przykład_pus		alculati					Properties	
							×	<u>ه</u>					No selection	🚽 🖳 🛃 😺
													General	
														ByLøyer
		+++++++++++												
		+++++++++++	++++++++++++++++++++++++++++++++++++	++++++	+++++++++++++++++++++++++++++++++++++++			umber f C						
			++++++++	+++++										
			 	╞┾┼┼┼┼	+++++++++++++++++++++++++++++++++++++++									
		++++++++++		+++++	+++++++++++++++++++++++++++++++++++++++									
		********											View	
									MS	Ma	MR	MC		
	HHHH													
							Se	cientific						
											log			
							Va	ariables						-
							U	nits Cor	wersio	in>>			Misc UCS Icon On	
Ġ→ X							Te	ext Calc	ulate>	`				
<pre>H & b Model Arkuszi Arkuszi X Pick second corner:</pre>														
How many horizontal lines:<0>20 How many vertical lines:<20>40														
Command:														
-1063.1286, -1573.6728, 0.0000		0 1 2 4 5 =	Ta 🗊											

6.39 Draws a series of arrows alongside points

The arrows are drawn between the points that the user chooses.


The first step after activating the command is choosing the starting point of an arrow which is to be inserted.




Following that, choosing different points will allow you to connect them with arrows.

6.40 🔀 Add arc


The function automatically allows us to add an arc to the indicated leaders.




After activating the function, indicate the elements on which you want to insert the arcs:




Then select the crossing element:



Next - under the cursor - you will see a preview of the arc:




When you specify the size and direction will be inserted into all previously marked leaders:




6.41 Remove points


We can easily remove the arc with the points that were created on the selected elements. To do this, after activating the function, specify the elements on which you want to remove the arcs and additional points:



Click the base point and select the area you want to remove.




The selected items will return to their original shape:




6.42 + Add point

The command allows you to add a point to an existing leader.

After activating the command you need to specify to which element you want add a point:




Next, you should specify this point in the drawing:



6.43 – Remove point

Similarly to the preceding function, we can easily remove the indicated point and return to the original state.


When you start the function, you need to specify the point you want to remove.





6.45 SZWToolbox 2020 User Manual

Gives access to the user manual.



You can check whether you have the most up to date version of the overlay.



After clicking "Next", the program will download and install a newer version of the overlay, if it is available.

7 Additional information

7.1 Manual load menu

In order to manually load menu, you have to write the command "__menuload" or go into menu: Tools->Customize->Menu. There, a window similar to the one below will be displayed.

Load/Unload Customizations	×
Loaded Customization	
APP+ ZWCAD	<u>U</u> nload
ZWToolbox 2018 0	
<u>F</u> ile Name:	Load Browse
	lose <u>H</u> elp

- a. Press the button "Browse"[1]. In the new window.
- 2. You need to look for the file called "ZWToolbox.cuix". Default path:
- 3. "C:\ Szansa\ZWToolbox\2020\EN\Menu".

4. It's location may be different. It all depends on the installation path which was chosen during the installation.

- a. Select the file by pressing "Open".
- b. Load the file by pressing "Load"[2].
- c. In the list [3] a confirmation text will appear.

d. The button "Close"[4] will close the window. ZWCAD will have a new toolbar once all the steps are done.

Load/Unload Customizations	×
Loaded Customization	
APP+ Unload	
ZWCAD	
ZWToolbox 2018 0 3	
Load	
Eile Name:	
Browse 2	
4	
	P

7.2 Manual load application

After installing the overlay, it should load automatically after running ZWCAD 2020. The functions should be available and the toolbar with the icons should be displayed. If after running ZWCAD the overlay does not appear, please follow these steps:

Run the command "_appload" or by using the menu in ZWCAD: Tools->Load Application: To begin the process follow these guidelines:

Application Files:	✓ Save updates	
	6	<u>A</u> dd File
		<u>R</u> emove File
		Load
		<u>U</u> nload
		Add to startup suite
		S <u>t</u> artup suite
		<u>o</u> k

Press the button "Add file"[6], select the file "ZWToolbox.zelx" [7] Confirm by pressing the button "Add"[8]

7 Otwieranie		×
← → × ↑ 📙 « OS (C:) → Szansa →	ZWToolbox > 2018 > EN > V	Przeszukaj: EN 🔎
Organizuj 👻 Nowy folder		III 🔻 🔟 😲
 Ten komputer Dokumenty Muzyka Obrazy Pobrane Pulpit Wideo Developerka (\\192.168.11.200) (B:) S (C:) 	Menu Axis.zelx CALC.zelx Global.zelx ZWToolbox.zelx	Data modyfikacji Typ 2017-09-26 15:16 Folder plików 2017-09-19 09:12 Plik ZELX 2017-09-19 09:12 Plik ZEXX
■ DATA (D:) ■ home (\\192.168.11.200) (H:) ■ Support (\\192.168.11.200) (M:) <u>N</u> azwa pliku:	• •	ZWCAD Applications (*.zrx;*.lsr, ~) Qtwórz
	8	

Following that, in previous window select on the list a newly added file [9] and load by pressing the button "Load" [10]

Load Application Files		×
Load Application Thes		^
Application Files:	∑ <u>S</u> ave updates	
9		Add File
	10	<u>R</u> emove File
		Load
	11	<u>U</u> nload
		Add to startup suite
		S <u>t</u> artup suite
		<u>0</u> K
Help		

You can also add an application to the list of applications, which start automatically when ZWCAD loads. To do this, you should follow the previous steps, and after the last step press the button [Add to startup suite] [11] and then press the button "**OK**".